

Installation Instructions

TOOLS REQUIRED:

- Allen Key - 4 mm
- Allen Key - 5 mm (MY13 and MY14 motorcycles)
- T45 Torx Wrench (MY15 motorcycles)

INCLUDED PARTS:

PART NUMBER	QTY	PART NAME
10-05950	1	Top Case Weldment Assembly
10-05956	1	Top Case Rubber Bumper
90-07273	2	Hexagon Socket Button Head Cap Screw - M6x16-8.8
90-07009	2	Hexagon Socket Button Head Dog Point Screw - M8x50

INSTALLATION:

1. On MY13 or MY14 motorcycles, remove seat bolts using 5 mm allen key and remove the seat. Retain for re-use, but if you happen to strip the heads, don't worry. We include two replacements, M8x50 Hexagon Socket Button Head Dog Point Screws.

On MY15 and later motorcycles remove the seat bolts using a T45 Torx wrench and retain for re-use. You won't need the extra M8x50 screws



Figure 1. Seat bolt on seat

2. Slide Top Case Rubber Bumper onto lower flange of the Top Case Weldment Assembly.



Figure 2. Bumper slides onto rack flange