

**INCLUDED PARTS (NOT SHOWN):**

PART NUMBER	QTY	PART NAME
10-06425	2	GIVI Side Case Mounting Hardware Junction Kit (E115F) - includes pyramid clamp, mushroom spacers with retention bolts and nylock nuts
20-00539	4	Cable tie, 4 in, black (two extra if needed)
20-01362	1	Cable tie, 6 in, black
90-07273	2	Hex socket button head screw M6 x 16 (used to attach side case seat brackets to frame)

**INSTALLATION:**

1. Remove the seat bolts using a T45 Torx wrench and retain for re-use. Remove seat.



Figure 1. Seat bolt location

2. Using flush cut snips, cut the zip ties holding the signal wires under the left rear of the seat area. Also cut the zip tie that secures the foam wrapped around the ferrite and remove foam. Retain foam for re-use.



Figure 2. Cut and remove zip tie



Figure 3. Rear ferrite wrapped in foam

3. Open the ferrite by carefully inserting two jeweler's screwdrivers in the holes shown in Figure 4. Squeeze them together and the ferrite should easily pull open.

NOTE: If you are doing a large number of installations, the ferrite manufacturer does make a special tool that can be obtained online. Contact Zero Motorcycles Customer Service for more information.



Figure 4. Holes for removal of ferrite

4. Disconnect turn signal wires and carefully pull them out through the tail. Make a mental note to remember how the wires connect (or take a picture).