BMS DIAGNOSTIC CABLE

Connect to Zero Power Pack



Molex 1510140008
50394-8200 pins

https://zeromanual.com/index.php/How_to_build_a_cable_to_access_the_MBB